


MONITORS AND THEIR ACCESSORIES

10 WHEEL MONITOR - (Part #ALTGPM10)

- Monitors 1 to 10 wheel positions
- Dimensions, Weight, Power = 6.5"W x 3.0"H x 0.5"D, 4 ounces, 12VDC
- For use on Auto, SUV, Heavy Equip, Ag, Bus, Truck
- Communicates (real time) via RS232 to a serial port
- Data Logging capabilities
- Antenna and power cord required - *sold separately*



16 WHEEL MONITOR - (Part #RVGPM16)

- Monitors 1 to 16 wheel positions (capable of reading primary and tow vehicle)
- Dimensions and Weight = 6.5"W x 3.0"H x 0.5"D, 4 ounces, 12VDC
- For use with RV, Bus, 5th Wheel, all Trailers (boat, motorcycle, snowmobile)
- Communicates (real time) via RS232 to a serial port for fleet applications
- Data Logging capabilities
- Antenna and power cord required - *sold separately*



34 WHEEL MONITOR - (Part #HDGPM34)

- Monitors 1 to 34 wheel positions - (capable of reading primary and tow vehicle)
- Dimensions and Weight = 6.5"W x 3.0"H x 0.5"D, 4 ounces, 12VDC
- For use with - Truck, Tractor/Trailer, Off Road (Mining), 5th Wheel
- Communicates (real time) via RS232 to a serial port for fleet applications
- Data Logging capabilities
- Antenna and power cord required - *sold separately*



INTELLIGENT "DROP & HOOK" MONITOR - (Part #ITMA16)

- Monitors 1 to 64 wheel positions (16 on Tractor, 16 per trailer, up to 3 trailers)
- Dimensions, Weight, Power = 6.5"W x 3.0"H x 0.5"D, 4 ounces, 12/24VDC
- For use with - Tractor/Trailer(s) for "Drop & Hook" applications
- Communicates with J1587 Intelligent Repeaters over the J2497/ABS Network
- Transfers data from J2497 network to Tractor J1708 network
- Antenna and power cord required - *sold separately*



INTELLIGENT PROGRAMMING MONITOR - (Part #IPM)

- Programming (display only) Monitor – cannot receive transmissions directly
- Dimensions, Weight, Power = 6.5"W x 3.0"H x 0.5"D, 4 ounces, 12/24VDC
- Used only for programming Intelligent product or as a pass through display when used in conjunction with J1939 Gateway
- Antenna and power cord required - *sold separately*



J1939 INTELLIGENT GATEWAY - (Part #GWA16)

- Monitors up to 16 tyres each on tractor/9 trailers/dollies - (160 tyres total)
- No user interface for Drop & Hook or Programming function
- Communicates with Universal Repeater over all truck networks
- Transfers data from trailer network to Tractor J1939 network
- Deutsch power cord & Cabled Antenna Kit required - *sold separately*



UNIVERSAL INTELLIGENT REPEATER - (Part #URA16)

- Monitors up to 16 wheel positions
- No user interface for Drop & Hook or Programming function
- Communicates with all trucking networks including J1587, J1939, CAN
- Transfers data over trailer network to Tractor J1939 or J1708 network
- Deutsch power cord & 7" Antenna Required - *sold separately*



MOTORCYCLE MONITOR - (Part #MOTO6)

- Monitors 1 to 6 wheel positions for bike/trike/trailer/sidecar
- Dimensions and Weight = 3.75" W x 1.6" H x .85" D, 2.5 ounces, 12VDC
- Built in 5' power wire with quick disconnect, hot/ground wires
- Weatherproof casing with built in antenna and automatic light sensor technology
- Continuous display of pressures (rotates positions every 2 sec)
- Handlebar Mount included
- *No upper pressure alert or high temperature alert*

